



NOTES:

- 1) ALL WIRING RUNS 2#12, #12G UNLESS SPECIFICALLY NOTED OTHERWISE.
- 2) MOUNT EXTERIOR AREA AND EMERGENCY LIGHTS WITH TOP 10'-0" AFF.
- 3) FASTEN INTERIOR LIGHTS TO CEILING WITH #12 SHEET METAL SCREWS EXCEPT WHERE LIGHTS CROSS STRUT USE 1/4" BOLTS & STRUT NUTS, TYP

2 LIGHTING PLAN
E4.1 3/8"=1'-0"